ASSEMBLY INSTRUCTIONS

ITEM NUMBER: #19033 Sectional DESCRIPTION: Power 6PC Sectional:

Thank you for purchasing this quality product. Please read instructions carefully prior to assembly.

Check carefully for small parts which may have come loose during transportation inside all the boxes.

Remove from boxes and place all parts and components on soft surface such as carpet, blanket or furniture pad. Identify and verify all parts and hardware as specified below.

PART LIST:

NO.	DESCRIPTION	OUTLOOK	QTY.	NO.	DESCRIPTION	OUTLOOK	QTY.
1	LAF RECLINER EAR		1	10	WEDGE BACK CUSHION		2
2	LAF RECLINER BACK CUSHION		1	11	WEDGE SEAT BASE		1
3	LAF SEAT BASE		1	12	RAF RECLINER EAR	D	1
4	CONSOLE BACK (IN THE BOTTOM OF CONSOLE BASE)		1	13	RAF RECLINER BACK CUSHION		1
5	CONSOLE BASE		1	14	RAF SEAT BASE		1
6	LAF 2ND SEAT BACK CUSHION		1	15	RAF 2ND SEAT BACK CUSHION		1
7	LAF 2ND SEAT BASE		1	16	RAF 2ND SEAT BASE		1
8	LAF:The main power cord is in the end of the seatbase	4	1	17	RAF:The main power cord is in the end of the seatbase	4	1
9	Reading light is in the storage console	10	1	18			

Installation Steps:

